



Protocol: Intra Multi-Des GA



DESCRIPTION OF PRODUCT

Disinfectant

COMPOSITION

Glutaraldehyde	125 g/l
Didecyldimethylammonium chloride	100 g/l
Alkyldimethylbenzylammonium chlorides	150 g/l

GENERAL PROPERTIES

- ✓ pH of working solution: independent
- ✓ Non-corrosive
- ✓ Residual activity

PACKAGE SIZES



DISINFECTING EMPTY GREENHOUSES



- 1 Spray 1% solution - (1 liter in 100 liter of water)
- 2 Use 3.500-5.000 litre/ha
- 3 Contact time 10 minutes - when new plants arrive within 72 hours, rinse with water
- 4 Intra Multi-Des GA is compatible with foaming applications (foam lance)

ALGAE REMOVAL



- 1 Spray 2% solution on the affected area with a low pressure sprayer (2 liter in 100 liter of water)
- 2 Let the product dry, no rinsing
- 3 Use on all kinds of surfaces; concrete, glass, ground cover, etc.

HYGIENE CARPET / BOOT DIP



- 1 Use a 2% solution of Intra Multi-Des GA (200 ml in 10 liter of water)
- 2 Refresh the carpet every 2-3 days or when you measure less than > 0.5% of activity with the test strips
- 3 The number of refreshments depends on the number of passes per day



DISINFECTING TOOLS AND MACHINERY



- 1 Daily cleaning and disinfecting of tools is important
- 2 In case of severe contamination, clean the surface first
- 3 For disinfection use 1% solution (100 ml in 10 liter of water)
- 4 Spray the tools, let it stay for 10 minutes, rinse the surfaces with clean water



PRECAUTIONS FOR THE CONCENTRATED PRODUCT



Avoid inhaling gases/mist/vapors



Wear protective clothing



AFTER INGESTION: in case of feeling unwell, consult a **POISON CONTROL CENTER**



IN CASE OF SKIN CONTACT:
wash with plenty of water and soap



IN CASE OF EYE CONTACT: rinse cautiously with water for several minutes. Remove contact lenses. If irritation persists, seek medical advice

PRODUCT HAZARDS

Intra Multi-Des GA is classified according to Regulation (EU) 1272/2008 (GHS) as:



Warning: To work safely with the product, protective clothing (eye protection, face mask, gloves) must be worn. Avoid any form of exposure to the product. Keep the product away from flammable materials (oil, clothing, etc.). In case of contact or spills, rinse immediately with tap water



INSTRUCTION FOR INTRA MULTI-DES GA TEST STRIPS

0 - 2% Intra Multi-Des Ga strips *(For use with solutions containing no surfactants)*

- 1 Dip the test strip into the solution to be tested and remove immediately. Do not shake.
- 2 Compare strip to color in the chart below within **5 seconds** for accurate results.

